




ROBATHERM

Proudly Distributed By

ROBAND 



OPERATING INSTRUCTIONS

COMMERCIAL MICROWAVE OVEN

Models: **RM1129** **Version 1**

- Features:**
- 1100W Power Output
 - Stainless Steel Construction
 - Ceramic Base
 - 10A Plug
 - Internal Capacity 29L
 - 20 Programmable menus + Multi-stage cooking
 - 18kg

Roband® Australia is a wholly Australian owned company and has been manufacturing quality commercial catering equipment for the food service industry for more than 50 years. Roband products are engineered and manufactured to the highest standards to provide functionality, reliability and durability, and our quality products are exported world-wide.

Included in the comprehensive Roband® range are Toasters, Fryers, Milkshake Mixers, Rotisseries, Food Display Cabinets and much more.

Roband® Australia also acts as the Australian agents for Vitamix® Blenders, Noaw® Meat Slicers, Förje® Cookware, Robalec™ Soup/Rice Warmers, Robatherm® Urns, Robatherm® Microwaves, Halde food processing machines, Austheat® Fryers, Dipol Induction & Autofry.

For a complete set of brochures please contact your nearest authorised dealer or Roband head office.

Roband Head Office Sydney, Australia	
Roband Australia Pty Ltd 1 Inman Road Dee Why NSW 2099 AUSTRALIA	Tel: +61 2 9971 1788 Fax: +61 2 9971 1336 Email: sales@roband.com.au Web: www.roband.com.au
International Agents For additional agents please email Head Office	
Belgium Linum Europe Ph: +32 (0)56 35 92 96	Noumea: Comptoir Materiel Professionnel Ph: +687 28 50 43
Germany Lölsberg Ph: +49 9305989780	Papua New Guinea: Brian Bell & Company Pty Ltd Ph: +675 325 5411
GREECE K&N Engineers Ltd Ph: +30 210 520 0440	Singapore: Allied Foodservice Equipment Ph: +65 62525880
Hong Kong: Chung Wah Kitchen Machine Ltd Ph: +852 2334 5411	South Africa Foodservice Solutions (Pty) Ltd Ph: +31 306 017 442
Italy NOAW Ph: +39 0331 219723	Thailand: Seven Five Distributors Co Ltd Ph: +662 866 5858
Malaysia: Allied Food Equipment Ph: +603 9133 5833	United Kingdom Metcalfe Catering Equipment Ph: +44 (0) 1766 830456
Maldives: Radiant Heat Maldives Pty Ltd Ph: +960 333 4845	United Arab Emirates: Boncafe Middle East LLC +9714 282 8742
New Zealand: Roband New Zealand Ph: +649 274 1354	United Arab Emirates: Nisa Trading LLC +9714 396 6132

© Copyright 2019 – Roband® Australia Pty Ltd

All rights reserved. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical, including photocopying or posting to a website, without the written permission of the publisher. The material contained within this document is intended entirely for instructional purposes.

CONTENTS

SPECIFICATIONS.....	3
SAFETY.....	4
CLEANING, CARE & MAINTENANCE	6
INSTALLATION	7
OPERATION.....	8
NORMAL COOKING - MANUAL OPERATION.....	8
DEFROST	9
QUICKSTART.....	9
PROGRAMMED MENU.....	10
CHECK PROGRAM.....	11
DOUBLE QUANTITY	12
POWER SAVE MODE	12
MUTE	12
CHILD SAFETY LOCK	12
ERROR CODE	12
MATERIALS SUITABLE FOR USE.....	13
TROUBLESHOOTING.....	13
NOTES	14
WARRANTY	15

SPECIFICATIONS

Model	RM1129
Power Source	230 Volts AC ~ 50Hz
Input Power	1600 Watts
Output Power	1100 Watts
Oven Capacity	29 Litres
Oven Cavity (W x D x H)	350 x 357 x 226 mm
External Dimensions (W x D x H)	542 x 461 x 329 mm (includes handle and standoff)
Net Weight	Approx. 18 Kg

Specifications subject to change without notice

SAFETY

GENERAL SAFETY WARNINGS

- Read and follow all instructions in this manual prior to using this product
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
- Touching internal electrical components may cause serious injury or death, even with the microwave unplugged. Do not remove cover unless qualified to do so.
- Do not cover or block filter or ventilation openings
- Keep cord away from heated surfaces
- This product is suitable for commercial use only

OPERATION SAFETY WARNINGS

- Do not operate oven without food or load in oven cavity
- Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the contents.
- The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- Only use utensils that are suitable for use in microwave ovens.
- Do not put metal in the oven
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition. If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- Eggs in their shell and` whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- The oven should be cleaned regularly and any food deposits should be removed. Failure to maintain the oven in a clean condition could lead to

deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

MICROWAVE SAFETY WARNINGS:

- If the door or door seals, door hinges or any part of the machine is damaged, the oven must not be operated until it has been repaired by an authorised person.
- Do not place any object between the oven front face and the door, or allow soil or cleaning residue to accumulate on sealing surfaces
- Do not attempt to operate this appliance with the door open.
- Do not tamper with interlock safety switches
- This product should not be repaired by anyone other than trained service personnel.

CLEANING, CARE & MAINTENANCE

IMPORTANT: Before cleaning or maintenance commences, ensure the microwave is disconnected from power and has cooled down.

- Toxic cleaners should be avoided when cleaning the inside of the Microwave as they may contact food.
- Caustic cleaners should always be avoided, as they may damage components inside and outside the unit.
- This unit is not suitable for cleaning with the use of a water jet or immersion.
- The door frame, seal and parts nearby must be cleaned carefully with a damp cloth when they are dirty.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, causing damage to the door or shielding mesh within.
- **CAUTION:** Do not wipe plastic and painted sections of the oven with bleach, thinners or other cleaning agents, as this may cause these parts to dissolve or change shape.
- If the supply cord is damaged it must be replaced by a cord set supplied by Roband. Internal maintenance should only be performed by a Roband appointed service agent or similarly qualified person in order to avoid a hazard.

Cleaning the control panel and plastic parts:

Do not use a detergent or an alkaline spray to clean the control panel or plastic parts as this may cause damage. Use a dry cloth to clean.

Cleaning the Microwave interior:

After use, clean up spilled liquids, spattered oil and food as quickly as possible. If the oven is used while dirty the efficiency drops and the food may get stuck on the interior. Clean the interior with a cloth soaked in warm water with mild detergent dissolved in it, and then rinse the soap off with a damp cloth.


INSTALLATION

IMPORTANT: DO NOT USE THE MICROWAVE DOOR HANDLE TO LIFT THE MICROWAVE OVEN.

- Remove all the packaging materials, tape and any protective film on the microwave and inside the oven cavity.
- Examine the microwave oven and report any damage immediately. Do not attempt to use the oven if there is damage
- Install on a stable, flat surface. This microwave is designed for counter use only.
- Product should be installed at counter height only (approximately 800-1100mm). Installing outside the recommended mounting height could cause damage to the door hinges and prevent operation.
- Allow at least 150mm clearance from top, back and sides when positioning the microwave
- Do not obstruct filter or ventilation openings
- Install away from TV and radio sets as reception and radio interference might be affected
- Do not position Microwave near heat, water, oil or steam
- Do not connect to power using an extension cord

WARNING: This product must be earthed. Ensure appliance is plugged into a properly earthed power outlet

OPERATION



1. **MICROWAVE** – Indicates when the microwave is in operation
2. **DEFROST** – indicates defrost setting
3. **POWER LEVEL** – Indicates power other than 100%
4. **CHILD LOCK** – Indicates Child lock is active
5. **PROGRAM**– Setup cooking programs
6. **DEFROST** – For using Defrost mode
7. **NUMBER 0-9** – To input time or program
8. **CHECK PROGRAM** – To view program settings
9. **x2** – Double time
10. **POWER LEVEL** – Used to set power level
11. **STOP / RESET** – To stop Cooking and Reset timer
12. **START / +30sec** – Begin/resume cooking or quickstart 30s

NORMAL COOKING - MANUAL OPERATION

- 1) Set Power level by pressing '**Power Level**' until desired power is displayed. Power will cycle through 100%, 80%, 60%, 40% and 20% with each press.

Note: The microwave will operate at 100% power if no power level is selected

- 2) Enter cooking time using the numeral keypad
- 3) Press '**Start**' to begin cooking
- 4) Cooking can be paused by pressing '**Stop**' once or by opening the door. To resume cooking while paused, press '**Start.**' Pressing '**Stop**' while paused will clear remaining time.

NOTE: The oven can be programmed for a maximum of 60 minutes, however if full power is selected, maximum time is limited to 20 minutes.

NOTE: Using a Low power may increase cooking time, but may produce a more uniform result in foods such as dairy and meats.

The cooling fan will run to prevent microwave components from overheating.

DEFROST

Defrost function cycles power intermittently to assist food to thaw evenly.

- 1) Press '**Defrost**' button
- 2) Enter desired time using numeral keypad (*Max defrost time is 60 minutes*)
- 3) Press '**Start**' to begin defrost

The DEFROST indicator lights on the display show the oven is in the DEFROST mode. The oven beeps during the defrosting cycle to signal that the food needs to be turned or rearranged. When the defrosting time ends, you will hear 3 beeps.

QUICKSTART

- 1) Press '**Start**' to begin cooking with a time of 30 seconds
- 2) Pressing '**Start**' again while running will add 30 seconds to the timer. By pressing multiple times up to 5 mins can be added.

Note: Quickstart always runs at 100% power

PROGRAMMED MENU

The microwave can store up to 20 Pre-Programmed Time / Power sequences. To select a pre-programmed sequence, touch the NUMBER pad for the desired program. To select program 10-20, touch the number pad twice rapidly. The oven will then begin the programmed cook sequence

Pre-Programmed Cooking Times and Power Level:

Number	Cooking Time	Power Level
1	0:10	100 %
2	0:20	100 %
3	0:30	100 %
4	0:45	100 %
5	1:00	100 %
6	1:30	100 %
7	2:00	100 %
8	3:00	100 %
9	4:00	100 %
10	5:00	100 %

SETTING PRE-PROGRAMMED SEQUENCE

- 1) Press '**Program**' button. The display will read "**PROGRAM**"
- 2) Enter the Program number to be changed. To select program 10-20, touch number pad twice rapidly, e.g. 1-1, 1-2 etc.
- 3) Press '**Power Level**' until desired power level is displayed
- 4) Enter time required using numeral keypad
- 5) Press '**Start**' to save or '**Stop**' to cancel

PROGRAMMED MENU - STAGED COOKING

Staged cooking sequences can also be saved to the programmed menu. A staged program will cook in 2-3 sequential time/Power stages.

- 1) Press '**Program**'
- 2) Enter the Program number to be changed (1-20)
- 3) Set power level for stage 1 by pressing '**Power Level**' until desired power is displayed
- 4) Enter time for Stage 1 using numeral keypad
- 5) Press '**Power Level**' again until desired power level for Stage 2 is displayed.
- 6) Enter time for Stage 2 using numeral keypad
- 7) Repeat Step 3 and 4 if a 3rd Stage is required
- 8) Once Power and time settings have been entered for required stages press '**Start**' to save or '**Stop**' to cancel programming
- 9) When a staged program is run the microwave will run through each stage automatically without user input. The display will show total time for all stages.

CHECK PROGRAM

Time and power settings for the Programmed menu buttons can be checked using this function.

- 1) Press '**Check Program**'
- 2) Enter the number (1-20) of the program you want to check
- 3) Display will show the time and power settings for each stage stored to the program entered.
- 4) Press '**Stop**' to end

DOUBLE QUANTITY

Selecting '**X2**' will temporarily double the program cooking time. First press '**X2**' then enter desired programmed menu.

Note: The extended cooking time cannot exceed maximum cooking time of 60 minutes, or 20 minutes at full power.

POWER SAVE MODE

Display is turned off when idle to save power. To activate, press and hold '**Check Program**' for 5 seconds. To use the microwave in Powersave press any button to wake the microwave. Once awake the microwave will operate as usual. To deactivate Powersave, press and hold any button and '**Check Program**' at the same time for 5 seconds.

MUTE

Stops beep when buttons are pressed. To activate press and hold '**X2**' for 5 seconds.

CHILD SAFETY LOCK

To activate press and hold '**Stop**' for 5 seconds. Unit is now locked and cannot be used until it is unlocked. To unlock press and hold '**Stop**' again for 5 seconds

ERROR CODE

- E10:** Maximum cooking time exceed in staged cooking. Total maximum cooking time is 20 minutes at 100% power or 60 minutes in other power levels. Press '**Stop**' to clear
- E20:** Program menu data unable to read or write.

MATERIALS SUITABLE FOR USE

- Items containing metal should not be used in the microwave as they may cause sparking. Even a small amount of metal plating on the edge of dishes and cups can cause sparking and should not be used.
- Combustible materials such as paper should be used with caution as they may ignite. Use only for short cooking times and only while attended.
- Plastic foam should not be used in the microwave as it may melt and contaminate food.
- Use only products marked as microwave safe for ceramic, glass and plastic products.

TROUBLESHOOTING

Only after all points below have been checked should you call for service:

If the Microwave is not working:

- ✓ Check that the machine is plugged into the power point correctly and the power is switched on and working.
- ✓ Check that the door is properly closed and not obstructed by food or any object.

If the Microwave is sparking in the cavity:

- ✓ Check that there are no metal utensils, metal containers or dishes with metal trim being used

NOTES

WARRANTY

The warranty conditions set out below are in addition to any warranties implied or governed by law.

Roband Australia warrants that this appliance shall be delivered free from defects in material and workmanship. The warranty for this product is offered to the original purchaser, to be free of fault in both workmanship and materials for a period of 12 months from date of purchase. Roband's obligations pursuant to this warranty are limited to the repair or replacement of the defective goods or materials, at its discretion and subject to the terms contained within this Warranty statement.

The following conditions apply;

The product must be installed, maintained and used under normal operating conditions within the scope of the operating instructions.

All warranty claims must be submitted to Roband or an authorised Roband dealer, and Roband authorisation must be granted prior to repairs being carried out. Proof of purchase is required for any repair authorisation.

Warranty is back to base, meaning delivery to and collection of your product to Roband or an authorized service agent is the responsibility of the purchaser.

The following exclusions apply;

Claims or faults arising from misuse, neglect, transport damage or other mechanical damage, including but not limited to; door's, hinges & interlock switches etc., other than those arising from manufacture or material defects.

Roband or any subsidiary company or Agent shall not be liable for loss of profit or damage to other equipment and property except where it is in breach of the guarantees provided in accordance with applicable legislation.

Roband reserves the right to reject a warranty claim if it is not satisfied with the circumstances under which the fault occurred or where a product has been altered from its original specification.

Any costs incurred for false claims or faults due to incorrect usage etc. are the responsibility of the claimant.

Any attempt to repair the product by non Roband approved service personnel or the use of non-genuine parts will void the warranty agreement

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Authorized service agents are located in most areas which have authorized distribution dealers. For the name of your nearest Australian authorised service agent, please contact:

Roband Australia Pty Ltd

1 Inman Road, Cromer, NSW 2099

Warranty: 1800 268 848, Phone: (02) 9971 1788 Fax: (02) 9971 1336

All other countries please contact your selling Agent.

Please complete the following details and keep this card in a safe place.

NAME _____

ADDRESS _____

MODEL No: _____ SERIAL No: _____ DATE PURCHASE _____

NAME OF DEALER: _____

PLEASE RETAIN THIS SECTION FOR YOUR RECORDS - **DO NOT POST**

OTHER PRODUCTS BY ROBAND:



FRY-POD FRYER



DRINK MIXERS



SYCLOID CONVEYOR TOASTER



GRILL STATION



VITAMIX BLENDER



NOAW SLICERS

Manufactured/Imported in Australia by:

ROBAND[®] 

Authorised Distributor/Agent